- prsnjaci kotúčovej brzdovej sústavy zgodne z normo ANSI/ASSE Z359.1-2007.

Ten produkt pracovnej jed do ochrany i zapobiegania ruchu upadku z wysokości w pracovnej, budowniczej, rolniczej i leśnej opłaty, w przypadku wszelkich zastosowań zgodnie z normą ANSI/ASSE Z359.1-2007. Ten produkt jest przeznaczony do użytku przez jedną osobę o wadze nie przekraczającej 130 kg (310 funtów) z maksymalnym przyrostem wzrostu wynoszącym 5 cm (2 cale). Ten produkt jest przeznaczony do użytku w temperaturach od -40 °C (-40 °F) do 54 °C (130 °F). Przed użyciem należy zapoznać się z całą instrukcją obsługi. Nieprzestrzeganie jako wskazówki może w chwili zdrowia lub wynikać śmiertelnych. Jeśli masz pytania dotyczące tego produktu, skontaktuj się z Tuxedo Coverall Ltd. Zachowaj tę instrukcję do wglądu. Jeśli sprzedajesz lub przekazujesz ten produkt innej osobie, upewnij się, że otrzymała ona również kopię tej instrukcji.

**Zastosowania** EN 795/B:2012

Ten produkt spełnia wymagania normy europejskiej dotyczące urządzeń do ochrony przed upadkiem z wysokości w zakresie wytrzymałości statycznej (typ. B), który obejmuje się według następującego wzoru: Współczynnik odpadnięcia = Wysokość spadania/długość liny. W przypadku, gdy współczynnik odpadnięcia wynosi 0 – co oznacza, że punkt kotwiczenia znajduje się bezpośrednio nad użytkownikiem, a wysokość spadania wynosi 0 – wówczas siła uderzenia wynosi 0 kN. W przypadku, gdy współczynnik odpadnięcia wynosi 2 – co oznacza, że wysokość spadania wynosi dwukrotność długości liny, a siła uderzenia wynosi 6

## ENGLISH

### GENERAL INFORMATION

The C.A.M.P. Group meets the needs of workers at height with light and safe personal protective devices. These are designed, tested and manufactured to a certified quality system, ensuring reliable and safe products. These instructions inform you about the correct use throughout the life of the product. **Read, understand, strictly respect and keep these instructions.** If lost, you can download the instructions from the web site **www.camp.it**. The EU declaration of conformity can be also downloaded from the web site. Personal protective equipment must be used by competent persons who have received adequate training in its use. This equipment should be used only by trained and competent persons. Otherwise the user should be under the direct supervision of a trained and competent person. This notice will not teach you the techniques for work at height or any other activity. Training in the use of this equipment is the responsibility of employers and self-employed persons. Choose the right product for which these products may be used, is inherently dangerous. The consequences of incorrect selection, misuse or poor maintenance of equipment could result in damage, serious injury or death. The user must be medically fit and capable to undertake work at height. If in doubt seek medical advice before using this equipment. The user must ensure that it is essential for safety that the anchor device or anchor point should always be positioned, and the work carried out in such way as to minimise both the potential for falls and the potential fall distance. Verify the free space required beneath the user at the workplace before each occasion of use, so that, in the case of a fall, there will be no collision with the ground or the other obstacle in the fall path. A full body harness is the only acceptable body holding device that can be used in a fall arrest system. Connecting devices must be used with a full body harness. Ensure that the fall arrest system is correctly assembled and that the appropriate item of suitable quality and according to the EU regulations, while the user is positioned in the harness. Carefully read and follow each individual piece of equipment. This leaflet shows examples of improper utilizations of this product. Note that it is impossible for C.A.M.P. to foresee all the possible ways in which its products may be used. Any use not explicitly approved by the manufacturer in this leaflet, if considered unsafe, is the user's responsibility. The user should be trained to perform the rescue instructions that be available for consultation and must be respected by all users.

**STORAGE** - Store unpacked in a cool, dry and well ventilated, dark place away from heat sources, high humidity, sharp edges, chemicals, corrosive substances, fuels, solvents or fuels which could affect the performance of the product.

**RESPONSIBILITY** – The company, its distributors, will not accept any responsibility for damage, injury or death resulting from misuse of or from modifications to a C.A.M.P. branded product. It is the user's responsibility at all times to ensure that he/she understands the correct use and safe use of any equipment supplied by or from C.A.M.P. SpA, that he/she uses it only for the purposes for which it is designed and that he/she practices all proper safety procedures. Before using the product, the user must read and understand the instructions for use. Anyone who does not understand these cannot use it. We personally assume all the risks and responsibilities for your actions and decisions. If you are not able or not in a position to assume these, do not use this equipment.

**WARRANTY** – C.A.M.P. products are warranted against any faults in materials or manufacture for 3 years from the purchase date. Limitations of warranty include normal wear and tear, modifications or alterations, incorrect storage, corrosion, damage due to accidents or negligence, use for which this product is not specifically designed.

### SPECIFIC INFORMATION

**INSTRUCTIONS FOR USE**

Summary:
C.A.M.P. Truck Loop is:
- Sustainable emergency anchor, certified as to standard EN 795:2012 Type B
- Lanyard certified as to standard EN 354:2010
- Energy absorber certified as to standard ANSI/ASSE Z359.1-2007

The product is intended for use to prevent and arrest against a fall falling from above in industry, in construction work, in rescue and, more generally, for any application of work at a height. C.A.M.P. Truck Loop is a stitched sling made up of a main webbing (**1**) inserted in a protective webbing sheath (**2**). Using this system the wear resistance is improved with respect to a normal sling. The internal webbing (**1**), can be used as a wear indicator: it will appear and can be seen if the outer web sleeve (**2**) is worn through. **Use only with C.A.M.P. connectors and carabiners compatible with the anchor.**

**Use as EN 795:B / EN 795:2012 Type B**

Truck Loop is used as portable anchor devices (EN 795/B) must be attached to structures for which the strength has been verified by a competent person. The anchor point must be positioned above the user's head and as close as possible to the line of the anchor point, fasten the lanyard as short as possible to limit the fall factor (**3-3.1**). Portable anchor devices must be used in such a way as to stay above the anchor point: risk of failure/injuries in case of fall. Take measures to avoid pendulum. If used in a fall arrest system (EN 363) Truck Loop must be connected to the energy absorber (**3-3.2**) and the minimum clearance must be at least 2 m when device is 9 kN. This force is transmitted to the structure, which must be able to withstand a minimum strength of 18 kN and of force direction. The deflection of Truck Loop used as anchor may get to 20% of its length. It is recommended to mark the device with the date of the first use. **Do not use the product if it is not clear which side is to be used. Do not use more than one device simultaneously by three people, thus becoming a collective protection device (TS 16415 not governed by EU regulation 2016/425).**

**Use as EN 354**

Fall factor is a rating used to evaluate the danger of specific scenarios when working at heights (**fig.3**). It is calculated using the formula fall factor = fall height / length of rope in use. The greater the fall factor, the greater the force on the rope. If the worker is positioned under the anchor point, the fall factor is 0 and the force on the rope is at its minimum. If the fall factor is 1, the force of movement is limited to 6.6 meters or less, positioning equipment is adequate. Fall arrest equipment must be used for other situations where the fall factor is 1 or greater. **Never use the lanyard in a configuration with a fall factor of 2** (**3-3.3**). Use connectors that ensure the strength of the energy absorber must be avoided. EN 354 certified lanyards (**3-3.4**) must be used with EN 362 certified connectors. Use only connectors with a minimum breaking strength of 20 kN. Connectors with a gate opening of 19 to 21 mm (EN 362) must be used with EN 354 certified lanyards (**3-3.5**). The following connectors are compatible: Zanurn+double+connector(s) must not exceed 2 meters and must be connected to a full-strength attachment point (≥15 kN) (**3-3.6**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.7**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.8**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.9**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.10**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.11**). Do not use the lanyard if the connectors are incompatible with the anchor point (**3-3.12**). Do not use the lanyard if the connectors are incompatible with the anchor point